

## NEW Edwards E2M28 Vacuum Pump



NEW Edwards E2M28 Vacuum Pump

Rating: Not Rated Yet

**Price:**

Variant price modifier:

Base price with tax:

Price with discount:

Salesprice with discount:

Sales price:

Sales price without tax:

Discount:

Tax amount:

[Ask a question about this product](#)

Manufacturer: [Edwards](#)

Description

### NEW Edwards E2M28 Vacuum Pump

#### Features and Benefits:

- The pump is designed for reliable, long-term operation.
- Thermal overload device prevents overheating (single phase only).
- The pump is a free-standing unit.
- The drive is provided through a flexible coupling by a single-phase motor.
- The motors are totally enclosed and are cooled by the motor-cooling fan.
- Pressure die cast oil box with integral oil seals prevents oil leaks.

- Gas ballast valve for large water vapor handling capacity.
- Externally approved to EN61010, CSA, C22.2 and UL61010.
- Oil sight-glass, two oil drain-plugs, inlet-port and outlet nozzle all fitted as standard.
- **ONE (1) YEAR WARRANTY**

**Specifications:**

- Disp. CFM @ 60 Hz: 22.3
- Ult. Pressure Torr:  $7.5 \times 10^{-4}$
- Motor HP: 1.2
- Oil Capacity Quarts: 1.6
- Oil Type: KJLSS 19
- Fomblin Estimate: 3 kg
- Inlet Flange: KF25
- Exhaust Flange: 15 mm Hose
- Weight lbs: 88
- Noise db: 57