

## New Varian DS602 Dual Stage Pump



The pump works with force-feed lubrication, provided by an auxiliary gear-pump driven by the rotor of the vacuum pump itself. This ensures proper lubrication even when pressures are close to atmospheric.

Rating: Not Rated Yet

**Price:**

Variant price modifier:

Base price with tax:

Price with discount:

Salesprice with discount:

Sales price:

Sales price without tax:

Discount:

Tax amount:

[Ask a question about this product](#)

Manufacturer: [Varian](#)

### Description

#### **New Varian DS602 Dual Stage Pump Call for Quote**

These pumps are Brand New in the factory boxes.

The DS602 pump is a dual-stage, rotary vane pump, oil sealed, pump driven by a single-phase electric motor.

#### Features:

- All parts in direct contact with the fluid pumped are free of copper alloys.
- All materials are carefully selected to provide extended life.
- A high capacity gas ballast device allow pumping condensable vapors.
- All the parts composing the pump are fully replaceable due to the close machining tolerances and to the centering obtained by using reference pins.
- Due to its design features and low number of gaskets, the pump requires little maintenance. Disassembly and reassemble are easy and require minimal time.

Includes **ONE (1) YEAR WARRANTY**

????????? ?????? : New Varian DS602 Dual Stage Pump

---